







Barrier to hole injection from metal into semiconductor Conduction band edge Fermi level Barrier to hole injection from metal to semiconductor No barrier to hole injection from metal to semiconductor Valence band edge

METAL 20

SEMICONDUCTOR
(N-TYPE) ( pr house!)

